

GasLab® Software Quick Start Guide

1.	Download and install the GasLab software from the CO2Meter.com website at: <u>http://www.co2meter.com/pages/downloads</u>	New Tab × ← → C
2.	Exit the GasLab software and unplug the US	B Cable.
3.	Start the GasLab software. Select the port dropdown in the lower left corner.	Port: COM1 - Product : CM-0001 -
4.	Plug the USB cable into your PC. A new COM port number should appear.*	Series / AQ-500 Auto Name: sensor Address: 254
5.	Select the new COM port.	Connect Deconvect
6.	Select your sensor model from the Product dropdown list.	
7.	Click Connect.	AQ-500[Co2 [K-30],Temperature [SHT11],H Connert Disconnect
8.	Click any enabled "Read" button to take a sensor reading.	Sensor Commands Auto-Logging Read Read Co2 Read Humidit Every 30 For 1 Hours
	See the manual for additional options or to begin data logging.	Temperature Concentration Celsius PPM Farenheit Percent

* Note: If a new COM# port does not appear in step 4:

Windows 7 Computers. Click this link and follow the instructions: https://www.ftdichip.com/Support/Documents/AppNotes/AN_119_FTDI_Drivers_Installation_Guide_fo r_Windows7.pdf

Windows 10 Computers. Click this link and follow the instructions:

https://www.ftdichip.com/Support/Documents/InstallGuides/AN_396%20FTDI%20Drivers%20Installati on%20Guide%20for%20Windows%2010.pdf