


ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	SE-0116-R	O-RING	1
2	SE-0116-S	#2-56 PHILLIP TORX SCREW, BLK STEEL	3
3	VDD-0019	K30 CO2 SENSOR	1
4	SCR-0039	18-8 S.S. #4-40 TORX PAN HEAD SELF TAPPING SCREW	2
5	MATL-0008	K30/K33 TUBE CAP PLATE	1
6	SE-0116	K30/K33 SENSOR CAP	1

NOTES:

1. DO NOT SCALE FROM THIS DRAWING.
2. NOTE ORIENTATION OF ADAPTER (ITEM #2). INCORRECT INSTALLATION MIGHT RESULT IN INPROPER OPERATION.
3. WHEN INSTALLING #4-40 SELF-TAPPING SCREWS (ITEM #6), SOME RESISTANCE IS TO BE EXPECTED AS THE SCREW IS CUTTING THREADS IN THE PLASTIC BASE OF THE SENSOR. DO NOT OVERTIGHTEN AS THREADS COULD BE STRIPPED DAMAGING THE SENSOR.

131 Business Center Building A-3 Ormond Beach, FL		 Toll free: 877.678.4259 Fax: 866.422.2356 www.co2meter.com	
Title K30/K33 ELG SENSOR TUBE CAP ADAPTER ASSEMBLY DRAWING			
APPROVALS DRAWN RJC CHECKED AR		DATE 4/15/2015 4/15/2015	
SIZE A		PART NO. CM-0114	
SCALE 3:2		THIRD ANGLE PROJECTION	
SHEET SHEET 1 OF 1		REV -	